



www.gillathletics.com
800-637-3090

395030 - ORBITER SPACER KIT INSTRUCTIONS

If your Orbiter has stretched beyond the legal length, you can shorten it by using the spacers (395030) included. The spacers are two small plastic sleeves.



1. Remove the threaded pin that connects the swivel to the rings on the harness.



2. Slide the rings of the harness into the swivel yoke. While re-installing the threaded pin, place the spacer between the yokes and run the pin through it. Tighten down the threaded pin.



The spacers effectively increase the diameter of the threaded pin and shorten the length of the Orbiter by the wall thickness of the spacer.

If the harness stretches further, you can add the second larger spacer over top of the first spacer.